
## **Setup Sheet for Program 1001**

JOB DESCRIPTION: Setup1

DOCUMENT PATH: Fixated machined clamp v12



Number Of Operations: 6
Number Of Tools: 3
Tools: T1 T2 T3
Maximum Z: 15mm
Minimum Z: -10mm
Maximum Feedrate: 1500mm/min
Maximum Spindle Speed: 24000rpm
Cutting Distance: 7265.78mm
Rapid Distance: 1393.87mm
Estimated Cycle Time: 6m:17s

Tools					
<b>T1</b> D1 L1			5		
Type: flat end mill	Minimum Z: -10mm	Holder: Maritool CAT40-ER32-2.35			
DIAMETER: 6mm	MAXIMUM FEED: 1500mm/min	VENDOR: Maritool			
Length: 32mm	MAXIMUM SPINDLE SPEED: 24000rpm	PRODUCT: CAT40-ER32-2.35			
FLUTES: 1	CUTTING DISTANCE: 6331.14mm				
DESCRIPTION: 6mm Flat single flute Endmill					
	ESTIMATED CYCLE TIME: 4m:29s (71.3%)				
<b>T2</b> D2 L2			<		
TYPE: flat end mill	<b>Мінімим Z: -</b> 9.8mm	HOLDER: Maritool CAT40-ER32-2.35			
DIAMETER: 3mm	MAXIMUM FEED: 1000mm/min	Vendor: Maritool			
Length: 20mm	MAXIMUM SPINDLE SPEED: 16000rpm	PRODUCT: CAT40-ER32-2.35			
FLUTES: 1	CUTTING DISTANCE: 604.32mm				
DESCRIPTION: 3mm Flat single flute Endmill	Rapid Distance: 80.32mm				
	ESTIMATED CYCLE TIME: 37s (9.9%)				
<b>T3</b> D3 L3					
Type: spot drill	Мінімим Z: -7.5mm	HOLDER: Maritool CAT40-ER32-2.35			
DIAMETER: 6mm	MAXIMUM FEED: 1000mm/min	Vendor: Maritool			
TIP ANGLE: 90°	MAXIMUM SPINDLE SPEED: 20000rpm	PRODUCT: CAT40-ER32-2.35			
LENGTH: 22.5mm	CUTTING DISTANCE: 330.31mm				
FLUTES: 3	Rapid Distance: 133.49mm				
DESCRIPTION: 6mm Spot Drill	ESTIMATED CYCLE TIME: 26s (6.9%)		U		

Operations					
Operation 1/6 DESCRIPTION: Adaptive1 STRATEGY: Adaptive WCS: #0 TOLERANCE: 0.1mm STOCK TO LEAVE: 0mm MAXIMUM STEPDOWN: 5mm OPTIMAL LOAD: 0.6mm LOAD DEVIATION: 0.06mm	MAXIMUM Z: 15mm MINIMUM Z: -10mm MAXIMUM SPINDLE SPEED: 24000rpm MAXIMUM FEEDRATE: 1500mm/min CUTTING DISTANCE: 5987.95mm RAPID DISTANCE: 1109.27mm ESTIMATED CYCLE TIME: 4m:13s (67.1%) COOLANT: Flood	T1 D1 L1 TYPE: flat end mill DIAMETER: 6mm LENGTH: 32mm FLUTES: 1 DESCRIPTION: 6mm Flat single flute Endmill			
Operation 2/6 DESCRIPTION: 2D Contour1 STRATEGY: Contour 2D WCS: #0 TOLERANCE: 0.01mm STOCK TO LEAVE: 0mm MAXIMUM STEPOVER: 5.7mm	MAXIMUM Z: 15mm MINIMUM Z: -10mm MAXIMUM SPINDLE SPEED: 24000rpm MAXIMUM FEEDRATE: 1500mm/min CUTTING DISTANCE: 183.18mm RAPID DISTANCE: 37.4mm ESTIMATED CYCLE TIME: 9s (2.3%) COOLANT: Flood	T1 D1 L1 TYPE: flat end mill DIAMETER: 6mm LENGTH: 32mm FLUTES: 1 DESCRIPTION: 6mm Flat single flute Endmill			
Operation 3/6 DESCRIPTION: 2D Contour1 (2) STRATEGY: Contour 2D WCS: #0 TOLERANCE: 0.01mm STOCK TO LEAVE: 0mm MAXIMUM STEPOVER: 5.7mm	MAXIMUM Z: 15mm MINIMUM Z: -6mm MAXIMUM SPINDLE SPEED: 24000rpm MAXIMUM FEEDRATE: 1500mm/min CUTTING DISTANCE: 160.01mm RAPID DISTANCE: 33.4mm ESTIMATED CYCLE TIME: 7S (2%) COOLANT: Flood	T1 D1 L1 TYPE: flat end mill DIAMETER: 6mm LENGTH: 32mm FLUTES: 1 DESCRIPTION: 6mm Flat single flute Endmill			
Operation 4/6 DESCRIPTION: Bore1 STRATEGY: Bore WCS: #0 TOLERANCE: 0.01mm STOCK TO LEAVE: 0mm	MAXIMUM Z: 15mm MINIMUM Z: -9.8mm MAXIMUM SPINDLE SPEED: 16000rpm MAXIMUM FEEDRATE: 1000mm/min CUTTING DISTANCE: 604.32mm RAPID DISTANCE: 80.32mm ESTIMATED CYCLE TIME: 37s (9.9%) COOLANT: Flood	T2 D2 L2 Type: flat end mill DIAMETER: 3mm LENGTH: 20mm FLUTES: 1 DESCRIPTION: 3mm Flat single flute Endmill			
Operation 5/6 DESCRIPTION: 2D Chamfer1 WCS: #0 TOLERANCE: 0.01mm STOCK TO LEAVE: 0mm	MAXIMUM Z: 15mm MINIMUM Z: -7.5mm MAXIMUM SPINDLE SPEED: 20000rpm MAXIMUM FEEDRATE: 1000mm/min CUTTING DISTANCE: 314.71mm RAPID DISTANCE: 65.09mm ESTIMATED CYCLE TIME: 22s (5.9%) COOLANT: Flood	T3 D3 L3 TYPE: Spot drill DIAMETER: 6mm TIP ANGLE: 90° LENGTH: 22.5mm FLUTES: 3 DESCRIPTION: 6mm Spot Drill			
Operation 6/6 DESCRIPTION: Drill1 STRATEGY: Drilling WCS: #0 TOLERANCE: 0.01mm	MAXIMUM Z: 15mm MINIMUM Z: -6mm MAXIMUM SPINDLE SPEED: 20000rpm MAXIMUM FEEDRATE: 333.333mm/min CUTTING DISTANCE: 15.6mm RAPID DISTANCE: 68.4mm ESTIMATED CYCLE TIME: 4S (1%) COOLANT: Flood	T3 D3 L3 Type: spot drill DIAMETER: 6mm TIP ANGLE: 90° LENGTH: 22.5mm FLUTES: 3 DESCRIPTION: 6mm Spot Drill			

Generated by <u>Fusion CAM 2.0.18961</u> Tuesday, April 23, 2024 21:36:17